

Door hinges can be adjusted in 3 directions

Use an Allen key to adjust.

See the image below.

